

Problem = bracket for the gas struts is starting to bend/separate down from the wall because I did not know where the gas struts would end up when I built the camper and did not put wood behind the  $\frac{1}{4}$  thin plywood on the outside



I cut this hole out thinking I could put wood behind it, glue it, and then screw into it, then the bracket would cover the same hole and you would never know it was there.





Problem is that the holes end up too close to the side of the wood and it splits ☹



